



Muzzle Brake Installation Instructions

1. Remove the magazine from the rifle and rack back the charging handle to eject any live rounds that may have been in the firing chamber. Clearing your firearm of any live ammo should always be the first step, regardless of the operation you are performing on the weapon.
2. Loosen and remove the thread protector or previous muzzle brake/flash hider (if there is one) from the barrel's muzzle threads. This allows you to install the new M+M Muzzle Brake onto the muzzle.
3. Place the muzzle brake over the muzzle of the barrel so that the prongs are facing away from the rifle.
4. Screw the muzzle brake counter clockwise onto the barrels muzzle threads. Continue tightening the brake down until you can no longer hand-tighten it.
5. Use a crescent wrench to torque the muzzle brake just past the point of being able to remove the muzzle brake by hand.

ACCURACY | RELIABILITY | QUALITY | INTEGRITY TM

M + M, Inc. TM

Northglenn CO 80233

Phone 866-926-5419 Fax 888-236-2619